

SampleIt Loom Stand

For the SampleIt Loom 25cm (10ins) and 40cm (16ins)



Ashford Guarantee

SL25LS300116V1

ASSEMBLY INSTRUCTIONS

- 1. Attach the base rail (with the Ashford logo) to one side and one foot and secure with a washer and knob. Note the tapered side fits snugly into the tapered rebate in the foot. Tighten the knobs to make the joint tight.
- 2. Attached the other side and foot. Secure with a washer and knob.
- 3. Push the 2 bolts through the holes in the side of the SampleIt loom. Locate the bolts into the grooves in the top on the loom stand and secure with washers and knobs.
- 4. Sit at the loom with your feet on the base rail. Loosen the knobs and tilt the loom until it is resting on your knees. Then re-tighten the knobs.

Now enjoy weaving on your SampleIt loom.

